

Current Release Version Firmware:

FW-SB7ECMX6Q-TP6K-Sukup-V1_03 **(Works on all current hardware versions)**

Old Release Versions Firmware

FW-SB7ECMX6Q-TP6K-Sukup-V1_02 **(Only Hardware Version 0, 1, & 2 , NOT HARDWARE VER3)**

TP 6000 Firmware Update:

Boot New TP6000 (First Time Only when new from Phoenix Contact)

Create Password: sukup1 (Hitting return, will move you to the second entry, you must enter it twice)

Every Time

When the Cockpit Screen opens, click the Icon in the middle of the screen (you only have a few seconds)

Click the ← twice, until it says Administration which is menu 9/10.

Click the Administration Logo

Enter in the password: sukup1 (Hitting return, will check password and enter menu)

If sukup1 does not work, try sukupmfg1 (Hitting return, will check password and enter menu)

Click "Update" on the left

Click "Choose Update File"

Expand "HardDisk" (Click the plus to the left of it)

Select Firmware Zip File (FW-SB7ECMX6Q-TP6K-Sukup-V0_01)(Version will change)

Click ✓ on the Popup Window

Click "Start Update"

Click ✓ on the Popup Window

Click ✓ on the Popup Window

Update will start and progress bar will move. At this point don't touch the screen or power it off.

(Takes several minutes)

When the screen reads: "Successfully Updated Firmware! Please reboot the device."

Click ✓ on the Popup Window

Click ✓ on the Main Window

Click the Reboot Icon (Bottom Left Button)

Click ✓ on the Popup Window – the Touchpanel will restart

Create Password: sukup1 (Hitting return, will move you to the second entry, you must enter it twice)

Device will reboot again, then when you are at the New Out of Box Software you are done.

Updating the Boot Image from Phoenix Contact to Sukup:

When the Cockpit Screen opens, click the Icon in the middle of the screen (you only have a few seconds)

Click the ← three times, until it says Customization which is menu 8/10.

Click the Customization Logo

Enter in the password: sukup1 (Hitting return, will check password and enter menu)

Click "Splashscreen" Tab on the left

Click "Browse Splashscreen"

Expand "FlashDrv" (Click the plus to the left of it)

Expand "SplashScreen" (Click the plus to the left of it)

Click "SplashScreen.bmp" (It will highlight)

Click ✓ on the Browse Popup Window

Click "Update Splashscreen Image"

Click ✓ on the Popup Window

Click ✓ on the Main Window

Click the Reboot Icon (Bottom Left Button)

Click ✓ on the Popup Window – the Touchpanel will restart